
THE BLUETOOTH SWITCH

The ideal accessory to the LONEALERT App. The bluetooth device uses low energy technology which is easy to set up, robust and reliable in tough environments, and has an extremely low power consumption.

Supports Android and iOs devices with Bluetooth 4. For security we recommend using latest version of operating systems and nothing older than Android 28 or iOS 7







How it works

The diverse range of lone worker environments means a growing demand for lone worker devices, apps and accessories. The Bluetooth Switch is a discreet, wearable and lightweight Bluetooth button that is easy to set up and can be worn as a watch, around your neck, as a keyring or in your pocket.

Using Bluetooth Low Power Smart technology, the Bluetooth Switch connects to the LONEALERT Access App. A simple press of the Bluetooth Switch will raise an alarm in the LONEALERT O.W.L. and open an audio channel to our dedicated response team.

If you don't use our response team, LONEALERT will initiate the calls, SMS and email notifications that you have designated as part of your response.

The Bluetooth Switch uses Bluetooth SMART technology that:


- Gives your loneworkers extra protection alongside the LONEALERT App.
- Allows lone workers to carry out their daily job role with added peace of mind, whatever their environment.
- Maximises productivity, therefore increasing efficiency.



Bluetooth Connection

All the features you need to give your lone workers added protection via the LONEALERT app

off depending on your requirements.



DISCREET & LIGHTWEIGHT

The bluetooth device is the size of a poker chip - weighing only 8 grams, 32mm wide and 10mm thick, it can be worn as a wrist strap, pendant or clipped on your belt.

FULLY CUSTOMISABLE

This device is fully customisable. For example, the duration of the countdown can be changed to 30, 90, 120 seconds or even turned off depending on your requirements. The device can also be set to VIBRATE for panic and alerts.

How far can the signal stretch?

The bluetooth button must be in range of your smartphone to operate

It has a wireless range of up to 75 feet indoor or up to 300 feet outdoor using Bluetooth 4.

*NB If the device travels out of range from your phone, both devices will receive an audio notification

For more information about Bluetooth Switch

Contact your Account Manager or call 0330 999 8484

